



HEMP CBD DISTILLATE FACE MASK

Consumer CBD fervor inspired this formulation. This luxurious treatment includes Hemp CBD Distillate and was designed to repair, protect and renew tired skin. **Meadowfoam Seed Oil** absorbs quickly and provides rapid, rich emollience. **Daikon Seed Extract** gives it comfortable slip and provides a light, non-greasiness. **Hemp CBD Distillate** is a phytocannabinoid-rich, full spectrum extract, which penetrates quickly to visibly calm inflammation and relieve fatigued, stressed skin. Aurafirm P is a fermented oat active, which has been proven to reduce skin roughness and increase skin radiance. Lecigel provides a soothing cooling sensation augmented by a subtly refreshing rose geranium and lemon fragrance blend. Just the pick-up tired skin needs to feel refreshed and restored!

Ingredient INCI NAME	Trade Name	%
Phase A		
Water	Deionized Water	87.37
Phytic Acid (and) Aqua	dermofeel PA ¹	0.10
Phase B		
Limnanthes Alba (Meadowfoam) Seed Oil	Meadowfoam XPR* ²	2.00
Raphanus Sativus (Radish) Seed Extract	Daikon Seed Extract ²	1.00
Glyceryl Stearate Citrate (and) Polyglyceryl-3 Stearate (and) Hydrogenated Lecithin	Heliofeel ³	2.00
Phytocannabinoid Rich Hemp Oil Distillate*	Hemp CBD Distillate ⁴	1.33
Helianthus Annuus (Sunflower) Seed Oil		0.10
Phase C		
Sodium Acrylates Copolymer (and) Lecithin	Lecigel ³	1.50
Xanthan Gum (and) Lecithin (and) Sclerotium Gum (and) Pullulan	Siligel ³	1.00
Benzyl Alcohol (and) Glyceryl Caprylate (and) Glyceryl Undecylenate	TRIstat ECO ⁵	1.00
Lactobacillus Ferment, Avena Sativa Kernel Extract, Sodium Benzoate, Potassium Sorbate	aurafirm P ⁶	2.00
Fragrance	Litsea Cubeba Essential Oil ⁷	0.10
Fragrance	Rose Geranium Essential Oil ⁷	0.50
Total		100

*Proposed INCI name

Suppliers: ¹ Evonik Dr Straetmans, ² Natural Plant Products; ³ Lucas Meyer Cosmetics; ⁴ Panacea Life Sciences; ⁵ Tri-K Industries; ⁶ Oat Cosmetics; ⁷ New Directions Aromatics

Procedure: Combine Phase A ingredients and heat to 75 – 80°C. In a separate vessel, combine Phase B ingredients and heat to 75 – 80°C. Add Phase B to Phase A with rapid propeller stirring. Remove from heat and continue to mix at moderate speed, immediately adding first two Phase C ingredients. Cool to 35°C, and mix in final four ingredients.

Stability: 1 month at RT and 45°C

The information contained herein is provided for informational purposes only. This suggested formulation is only a representative formulation and is not a commercialized product. NPP believes that the formulation and data on which this formulation is based are reliable, but it has not been subjected to extensive testing for performance, efficacy, or safety. Before commercializing, you should thoroughly test the formulation or any variation of it (as well as the raw materials, including any NPP product used) to determine its performance, efficacy, and safety. Further, you will be responsible for ensuring the regulatory compliance of the final product and its ingredients.

No guarantee, representation, or warranty of any kind is made with respect to any product or information contained herein, including, without limitation, the suitability, accuracy, the completeness or relevance of the data set out herein, or any result. NPP disclaims all warranties, express or implied, including, without limitation, warranties of merchantability, fitness for a particular purpose, or non-infringement of any patent or other intellectual property right (including, without limitation, copyright and trademark). User bears full responsibility for making its own determination as to the suitability for a particular purpose and for identifying and performing all tests and analyses necessary and sufficient for user's purpose. The final choice of use of a product or information as well as the investigation of any possible violation of intellectual property rights remains the sole responsibility of user.

© Natural Plant Products, Inc. All rights reserved.

Phone: (503) 363-6402
Fax: (503) 587-8717
Email: sales@meadowfoam.com

P.O. Box 4306
Salem, OR 97302 USA

www.meadowfoam.com